banner®



Measuring Guide

Chest (At 2cm from under arm)

Measure across the chest at 2cm below the underarm with the garment laid flat.

Front Length

Measure from the side neck point of the shoulder down to the hemline.

Sleeve Length (Including Cuff)

With the sleeve laid flat measure from the shoulder to the cuff edge.



APTUS Essentials Full Zip Top Code: AAAA112310

APTUS Essentials Full Zip Top												
To fit chest (Inches)						30/32"	32/34"	34/36"	38/40"	42/44"	46/48"	50/52"
To fit Age	3/4	4/5	5/6	7/8	9/10							
Chest (cm)*	32.5	34	36	39	42.5	48	50.7	53.3	58.5	63.7	68.9	74.1
Front length (cm)	41.5	42.5	47	51	57	63	69	74	77	79	82	84
Sleeve length (cm)*	35	37	39	43	48.6	54.5	59	63	65.5	69	70.5	72

^{*}Please note these are garment measurements - NOT body measurements.

PLEASE NOTE THAT GARMENT MEASUREMENTS AND SIZE ARE A GUIDELINE TO BRITISH STANDARD SIZING.